

# BOTTLE ROCKET USER INSTRUCTIONS

1. Start by sliding the end of the longest non-perforated stem (C) through the Bottle Rocket (F) from the bottom.

Then attach the free end of the silicone whip (E) to it and move the stem downward until the silicone whip touches the wood of the Bottle Rocket.

**NOTE: Do not allow the coupler to slide up inside the Bottle Rocket at the bottom or it will block airflow from inside the bottle. (See diagram to the right)**

2. Hold the Bottle Rocket up to the outside of the bottle you plan to use and 'eyeball' which perforated down stem (A & B) you should connect to the coupler. Choose the longest one that will fit the height of your bottle and connect to the coupler.

3. Fill the bottle about halfway with water, then insert the straw, pressing down slightly on the top of the Bottle Rocket to form a seal.
4. Attach the shorter non-perforated stem (D) in the side of the Bottle Rocket – this will be used as a draw stem.
5. Connect the other end of the silicone whip to your preloaded Launch Box or Muad-Dib Concentrate Box, engage power, then draw, bubble, and enjoy!

